


Garage Parking Sensor

Safely park your vehicle every time



GREEN LIGHT - PROCEED



AMBER LIGHT - SLOW DOWN



RED LIGHT - STOP

Simple. Smart. Safe

- Quick & Easy to install, designed to help you easily park your vehicle in your garage by providing a visual indication of your proximity to the wall.
- Position the Garage Parking Sensor to line up with the bumper of your vehicle. Extend the indicator light on its retractable cable until it's the perfect height for you to see it – That's all there is to it!
- Set the safety distance to 1, 2 or 3ft (30, 60 or 90cm) away from wall and the indicator lights will change color depending on your proximity.
- Green Light = the car has entered the detection zone.
Amber Light = the car needs to slow down and proceed with caution.
Red Light = the car is very close to the wall and you need to stop immediately.
- Wireless operation using 4 x AA batteries*
(*not included, indicator light flashes red when batteries need replacing)



What's in the box

- 1 x Garage Parking Sensor
- 3 x Wall fixings
- 1 x Operating Instructions

Part No. HGWGP580
UPC: 5060442175808



HGWGP580